Dante AV Test Drive
Recipes

Break free from cable limitations:
Use IP to bring your camera into meeting room

Lumens VC-TR60A
Camera

Lumens OIP-60D
Decoder / USB bridge

Your Meeting Room PC
Teams/Zoom/WebEx/TenCent/
Google Meet/Etc

USB

Ethernet

Netgear Switch

Ethernet

Your Dante Mic

Your Dante Speaker/Sound Bar

AUDINATE

Send One Source to Multiple Places:
Hardware and Software

Lumens VC-TR60a
Camera

- Camera in Multicast

Your Meeting Room PC

Dante Studio Rx
- AV-H camera
- Use DVS for audio

Ethernet

Netgear Switch

AMX AV-H RX
Decoder

HDMI

Your Dante Mic

Ethernet

Your Dante Speaker/Sound Bar

Switch display between presentation & camera

Lumens VC-TR60a
Camera

• Camera in Multicast

Your Zoom Rooms PC / VMR

Netgear Switch

Dante Studio Rx
- AV-H camera
- AV-H decoder

Ethernet

HDMI

Laptop

AMX AV-H RX
HDMI decoder

HDMI

AMX AV-H TX
HDMI encoder

Your Dante Mic

Ethernet

Your Dante Speaker/Sound Bar

• Use Dante Controller to
route Camera or Encoder
video to Decoder to
switch display source

AUDINATE

Corporate or lecture theatre presentation with high-fidelity visual content

Lumens VC-TR60a Camera

Your Meeting Room PC

Netgear Switch

Ethernet

Dante Studio Rx
- AV-H camera
- AV Ultra TX encoder from laptop
- Use DVS for audio

HDMI

Laptop
• High-detail desktop content

ADTECHNO AV Ultra TX HDMI/SDI Encoder

ADTECHNO AV Ultra RX HDMI/SDI Decoder

HDMI

• High-fidelity, low-latency presentation

Your Dante Mic

Ethernet

Your Dante Speaker/Sound Bar

Lecture Hall with in-room USB connection
Presentation share with AV Ultra | Conference with AV-H

Lumens VC-TR60a Camera

Overflow
- Send to more rooms on the network or other buildings with Dante Director

Your Meeting Room PC

USB

Netgear Switch

Ethernet

Lumens OIP-60D Decoder / USB bridge

Laptop
- High-detail desktop content

HDMI

ADTECHNO AV Ultra TX HDMI/SDI Encoder

ADTECHNO AV Ultra RX HDMI/SDI Decoder

HDMI

- High-fidelity, low-latency presentation

Your Dante Mic

Ethernet

Your Dante Speaker/Sound Bar

AUDINATE